

RCBS®

COMPETITION POWDER MEASURE



**WARNING:
NOT FOR USE WITH
BLACK POWDER!**

PRODUCT INSTRUCTIONS

SAFETY

Reloading is an enjoyable and rewarding hobby that is easily conducted with safety. But carelessness or negligence can make reloading hazardous. This product has been designed from the beginning with the user's safety in mind.

As with any reloading operation, some safety rules must be followed. By observing these few rules, the chance of hazardous occurrence causing damage or injury becomes extremely remote.

GENERAL

- Use the equipment as the manufacturer recommends. Study the instructions carefully and become thoroughly familiar with the operation of the product. Don't take short cuts.
- Observe "good housekeeping" in the work area. Keep tools and components neat, clean and orderly. Promptly clean up any powder spills.
- Always wear adequate eye protection.
- If any unusual resistance is encountered when moving the operating handle, STOP IMMEDIATELY and investigate the cause. To proceed against unusual resistance may damage equipment and/or cause serious injury!

LOADING DATA

- Use only laboratory tested data. We highly recommend the use of the SPEER Reloading Manual.
- OBSERVE ALL WARNINGS ABOUT THE USE OF MAXIMUM LISTED LOADS.

POWDER HANDLING

- Store primers and powder beyond the reach of children and away from heat, dampness, open flames and electrical equipment.
- DO NOT use any powder unless its identity is positively known. Discard all mixed powders and those of uncertain or unknown identity.
- Before charging cases, settle the powder in the powder hopper. Throw and check the weight of at least ten charges. This will assure you that the correct powder charge is being thrown.
- Use of a powder baffle will help to throw consistent charges.
- After a reloading session ends, pour the remaining powder back in its original factory container. This will preserve the identity and shelf life of the powder.
- DO NOT smoke while handling powder or primers.
- DO NOT USE BLACK POWDER with the Competition Powder Measure.

RECORD KEEPING

- Keep complete records of reloads. Apply a descriptive label to each box showing the date produced, and the primer, powder and bullet used. Labels for this purpose are packed with SPEER bullets.

Since RCBS has no control over the choice of components, the manner in which they are assembled, the use of this product, or the firearms in which the resulting ammunition may be used, no responsibility, either expressed or implied, is assumed for the use of ammunition reloaded with this tool.

NOT FOR USE WITH BLACK POWDER

GENERAL INFORMATION

The Uniflow Powder Measure will perform two powder charging tasks in one fast, simple operation. With each turn of the handle it accurately measures powder within a fraction of a grain and swiftly dispenses it into cases, one after another. Powder pours uniformly from the powder hopper into the measuring cylinder, through the drop tube and into the case. This eliminates the hazards of overloads caused by clogging when charges are dumped into cases. You can change from one charge to another quickly and easily with the Micrometer measuring screw which also serves as a reference for future charges.

The powder level is visible at all times through a large capacity five inch plastic powder hopper.


The measuring cylinder has a precision-ground surface and slides into the honed main casting for a precise fit. The lower portion of the main casting has the standard 7/8"-14 threads and may be used with the furnished stand plate or an optional Powder Measure/Piggyback Stand.

A powder measure is basically a device which measures powder by volume and not by weight. However, before you start throwing a given charge with this powder measure, the first charge must always be weighted on a powder scale to arrive at the desired charge. Accurate powder measure charges will also depend upon the size and uniformity of the powder kernels used, and how smoothly and uniformly you operate the powder measure handle.

Ball and flake powders will measure very evenly. Long and short kernel stick-type powders are more difficult to measure consistently, and it is imperative that you follow a set routine when throwing charges of these powders.

TO ASSEMBLE

To prepare the Uniflow Powder Measure for use, the measuring cylinder, Micrometer measuring screw, inside of main casting and powder funnel portion of main casting must be cleaned to remove the factory applied rust preventative. Failure to do so will cause inconsistent powder charges.



Insert screws through the handle and attach to the measuring cylinder with handle facing toward the unthreaded portion of the measuring cylinder. Carefully insert the assembly into the Uniflow main casting, this is a precise fit, do not force the cylinder into the casting. The Powder Measure can be set up for right or left handed use depending on which way you slide in the assembly.

With no washers (shims) on the Micrometer body, screw into the measuring cylinder with finger pressure, note where the scale or index lines are. Each washer will move the scale $\frac{1}{4}$ turn counter clockwise to allow it to line up near the top of the Micrometer body. For example: if the scale is @9:00 position-all three washers are required, @6:00 position-two washers required, @3:00 position-one washer and none are needed if the scale is @12:00 position. The Micrometer body must be removed to complete the assembly process.



No washers required



Three washers required


For the Rifle (large) measuring cylinder, insert the large measuring screw into the hopper, threaded end first and allow it to fall through the measuring cylinder until it comes to a stop. Thread the Micrometer body, with the appropriate number of washers, onto the measuring screw until about 1" of the measuring screw is exposed. Thread the Micrometer body assembly into the measuring cylinder and tighten. To set the 'zero' of the Micrometer. Rotate the measuring cylinder assembly so that the adjustment screw is perpendicular to the body of the powder measure. Lightly screw the end of the measuring screw in until it comes to a stop, back it off slightly. Slide the Micrometer thimble over the end of the measuring screw and align the scale marks to "0". Tighten the set screw in the side of the Micrometer thimble.




Inserting Rifle Measuring Screw Into measuring Cylinder



Attaching Micrometer body to Measuring screw




Installing Micrometer assembly to measuring cylinder



Positioning to 'zero'



locking in 'zero'



Pistol Micrometer
Installation

Rotate the handle to insure that the Measuring screw is not rubbing against the casting. If so, loosen a few graduations and reset the 'zero' of the micrometer.

For the Pistol/Small Rifle (small) measuring cylinder, thread the measuring screw into the Micrometer body until about 1" of the screw is exposed. Carefully thread the assembly into the measuring cylinder and secure. Follow directions above to set 'zero'.

Drop in the powder baffle and thread the stand plate to the bottom of the powder measure and lock in place with the lock nut. The stand plate can be mounted on a bench using wood screws; or it can be mounted on the left or right side of your reloading press and firmly held in place under the lock ring of a reloading die. An optional Powder Measure Stand is available from your reloading dealer. Two drop tubes are also furnished; one with a small hole for .22 to 7mm calibers, and one with a large hold for .30 caliber on up. An optional .17 caliber drop tube is available from your dealer.



Installing powder baffle



Completed assembly

TO USE

Before attempting to throw a series of powder charges, set the powder measure for the maximum charge and run about a pound of powder through it. This will deposit a film on the inside of the measure and help the powder flow through more evenly and consistently.

Be sure you see the same uniform movements for each powder charge. To throw a charge, raise the handle until it comes to the end of the stroke with a light tap. Then lower the handle in the same manner. This tap at the end of each stroke helps to settle the powder uniformly in the measure.

A dependable powder scale should be used to set the first charges in the powder measure as follows: throw a powder charge directly into the scale pan by raising the handle and lowering it. Weigh the charge. If it is too heavy, adjust the measuring screw with the handle in the down position to a lower number. If the charge is too light, adjust the measuring screw to a higher number. When you arrive at the exact charge you need note the reading on the Micrometer and you're ready to throw a series of charges. Write down the Micrometer setting for the powder and weight being used and you can quickly reset the powder measure the next time this charge is required.

As a precaution, throw every tenth charge into the scale pan and weigh it to be sure of consistency.

It is not necessary to empty the powder hopper each time you change charges unless a different powder is required.

Powder should not be left in the measure, as it will deteriorate and may clog and jam the measuring cylinder and etch the powder hopper. The measure can be emptied without taking it off the bench or reloading press by setting the measuring screw for the maximum charge and throwing charges until the powder hopper is empty.

TO REMOVE A CYLINDER

To remove a measuring cylinder for cleaning, first remove the Micrometer measuring screw assembly in the reverse order of how you assembled it. The Pistol/Small Rifle assembly can be removed from the front of the powder measure but the Rifle assembly must be disassembled and the measuring screw must be removed through the top of the powder measure.

Do not attempt to remove the powder hopper from the main casting.



PRECISIONEERED RELOADING EQUIPMENT

We think that we make the very best reloading equipment in the world. If you agree, please tell your friends. If you disagree, tell us we want to do something about it!

Customer Service

1-800-533-5000 (US or Canada) or 530-533-5191

Hours: Monday - Thursday, 6:30am - 3:00pm Pacific Time
(hours may vary)

e-mail: rcbs.tech@atk.com or visit our website at www.rcbs.com

RCBS 605 Oro Dam Blvd. Oroville, CA 95965

CCI - SPEER - RCBS
OUTERS - RAMLINE - ORBEX - FEDERAL