




MOE[®] AK+ GRIP

MOE



⚠ WARNING

BEFORE STARTING! MAKE SURE THE WEAPON IS UNLOADED,
THE CHAMBER IS EMPTY & THE SAFETY IS ENGAGED.




READ ALL INSTRUCTIONS BEFORE PROCEEDING
TO AVOID LOSING ANY SMALL COMPONENTS.



MOE AK+ GRIP INSTALLATION INSTRUCTIONS




IMPROPER INSTALLATION AND/OR IMPROPER
USE OF THIS PRODUCT MAY CAUSE WEAPON
MALFUNCTION. WEAPON MALFUNCTION MAY
CAUSE SERIOUS INJURY, INCLUDING GRIEVOUS
BODILY HARM AND/OR DEATH.




STEP 1: REMOVE ORIGINAL GRIP

Turn rifle upside down. Remove original grip per
armory guidelines. Take note of *grip nut*
orientation in receiver.




STEP 2: REMOVE GRIP CAP

To remove the *Grip Cap*, use thumb and middle
finger to hold the *Cap Extensions* that stick out
either side (A). Using index finger, push the *Cap
Locking Tab* (B) towards the rear of the grip at the
same time pulling the Cap down and free of the
Grip Body.



STEP 3: INSTALL GRIP

Position *grip nut* in receiver. Fit MOE AK+ *Grip*
onto lower receiver. Using a *flat-head screw*
driver install the supplied *Pan-Head Screw*
through the front hole and hand tighten. Reinstall
Grip Cap.



STEP 5: VERIFY INSTALL

Perform final inspection including function check
to verify proper weapon function.

***Always test fire your weapon before using it in
an operational environment.***